

TORKRÅD

Torkskåp med avfuktare TS 120A/D

Det har nu installerats ett energibesparande och miljövänligt torkskåp (innehållande kondensavfuktare) i ert torkrum.

Torkning sker genom att kondensera bort fukten i kläderna till vatten.

- Börja med att tvätta och torka de tjocka plaggen först.
- Tvätten skall centrifugeras i minst 5 minuter före torkning.
- Häng de kraftiga/tjocka plaggen längst ned i torkskåpet och de tunnare som lakan t-shirt och dyl. längst upp i torkskåpet.
- Start av torkskåpet sker via grön "start-knapp".
Inställd torktid är 60 minuter. Efter inställd tid avbryts torkningen.
- *OBS! Se till att dörrarna är stängda. Torkskåpet går ej att köra med öppna dörrar.*
- **Att avbyta torkningen sker via tryck på röd "stopp-knapp".**
OBS! Lämna dörrarna öppna efter avslutad torkning.
- **Efter att "stopp-knappen" tryckts in kan cirkulationsfläkten automatiskt fortsätta att gå för att kyla ned maskinen. Se då till att dörrarna är öppna för att påskynda avkylningen.**
- Återstart via "start-knappen" kan ej ske förrän avkylningen är klar, det vill säga då cirkulationsfläkten har stannat.

OBS! Tryck ej på stopp-knapp och sedan start-knapp fram och tillbaks i onödan.

Byt filtret regelbundet, efter max 1600 timmars driftstid eller minst var 6:e månad.
Filtret sitter bakom filterlucka på maskinens front.

DRYING ADVICE

Drying cabinet with dehumidifier TS 120A/D

You have just installed an energy-efficient, environmentally friendly drying cabinet (with a dehumidifier) in your drying room.

It dries by condensing the moisture out of the laundry and transforming it into water.

- Wash and dry the thickest laundry items first.
The laundry should be spun for at least 5 minutes before drying.
- Hang thicker/heavier laundry items at the bottom of the drying cabinet and thinner items such as sheets and T-shirts at the top.
- Start the drying cabinet by pressing the green Start button. The set drying cycle is 60 minutes. The drying process will stop after the set time has elapsed.
- *NOTE! Make sure the doors are closed. The cabinet will not operate with the doors open.*
- **To interrupt the drying cycle, press the red Stop button.**
NOTE! Leave the doors open after the drying cycle is completed.
- **The circulation fan can be set to automatically continue running to cool the machine after the Stop button is pressed. If this mode is used, leave the doors open while the fan is running to shorten the cooling time.**
- The machine cannot be restarted via the Start button until the cooling cycle has finished and the circulation fan has stopped.

NOTE! Do not repeatedly press Stop followed by Start unless absolutely necessary.

The filter should be replaced regularly after a maximum of 1,600 operating hours or at least once every six months.

The filter is located behind the filter hatch on the front of the machine.