

- Mount the switch in a suitable location that will not interfere with the steering when at full lock. Using either the clutch perch or front master cylinder
- Wire the switch into the PCV or Ignition Module (depending on your setup) into Input 1 or 2 (see PCV install guide)
- The switch has indentations next to each position that correlate to the Map position within the PCV software.



- Make sure you choose the correct Switch Input position that correlates to the feature in which you are using the switch for. This can be done in Power Commander Tools - Configure - Features Enables and Input Selections

www.powercommander.com



- Mount the switch in a suitable location that will not interfere with the steering when at full lock. Using either the clutch perch or front master cylinder
- Wire the switch into the PCV or Ignition Module (depending on your setup) into Input 1 or 2.
- The switch has indentations next to each position that correlate to the Map position within the PCV software.



- Make sure you choose the correct Switch Input position that correlates to the feature in which you are using the switch for. This can be done in Power Commander Tools - Configure - Features Enables and Input Selections

www.powercommander.com

