

RR BRAKE RESERVOIR COVER

Harley Davidson Pan America Installation Guide

PARTS LIST



1 RESERVOIR COVER



BOLT

PLEASE READ ALL DIRECTIONS BEFORE STARTING INSTALLATION



61300095



INSTALLATION

On the right hand side of the motorcycle remove the stock 6mm bolt holding the rear brake reservoir to the frame.



REMOVE STOCK HARDWARE

Install the Dynojet brake reservoir cover using the supplied hardware.

It is recommended to use BLUE loctite on the supplied 6mm allen bolt.



INSTALL USING SUPPLIED HARDWARE



PUSH THE LIMIT

2191 MENDENHALL DRIVE, NORTH LAS VEGAS, NV 89081 - 800-992-4993 - DYNOJET.COM
© 2019 DYNOJET RESEARCH ALL RIGHTS RESERVED