





Nº	CODE	DESCRIPTION
1	BP814S01	AIR MOTOR ASSY
2	BP814S02	END CAP SWITCH ASSY
3	BP814S03	EN CAP SCREWS
4	BP814S04	HAMMER CASE ASSY
5	BP814S05	ANVIL ASSY
6	BP814S06	HAMMER DOGS-PIN SET
7	BP814S07	HAMMER FRAME
8	BP814S08	HOUSING ASSY
9	BP814S09	MAINTENANCE KIT

MAINTENANCE KIT:

- 6 rotor blades
- 1 Rear gasket
- 1 front gasket
- 1 anvil O-ring
- 1 anvil clip
- 1 air valve spacer-gasket



BP814S



Not numbered parts are shown drawing for illustration purposes. Available parts are supplied by kits but not individually.

SNA Europe does not cover the causes over negligence in tool use and/or repair, inadequate care, or abnormal usage conditions. Follow the instructions for proper use, safety, maintenance and servicing given by SNA Europe

Revision: 00

10052025