









FN1650.2

ITEM	ITW-Eurocode	DESCRIPTION
	529918	FN1650.2 Sequential
1	617539	Screw
2	617556	Pushing
3	617504	Exhaust Cover
4	529913	Spring
5	617533	Screw
6	617535	Washer
7	617489	Cylinder Cap
8	617550	Gasket
9	617548	Seal
10	617519	Spring
11	617521	O-Ring
12	617510	Valve
13	617527	O-Ring
14	617507	Piston Stop
15	617552	Headrest Washer
16	617551	Cylinder Seal
17	617523	O-Ring
18	529914	Piston Unit
19	617505	Cylinder
20	617524	O-Ring
21	617525	O-Ring
22	617503	Collar
23	617522	O-Ring
24	617506	Bumper
25	617508	Joint Guide
26	617526	O-Ring
27	617545	Logo-1
28	617488	Body
29	529915	Trigger Valve Unit
30	529916	Spring
31	529917	Trigger Contact Kit
32	529918	Trigger Sequential
33	617537	Spring Pin
34	617553	Safety Bracket
35	529919	Spring
40	529920	Safety Lever Unit
41	617544	Logo-2
42	617549	Gasket
43	617529	Pin
44	529943	Driver Guide
45	617531	Screw
46	529922	Screw
47	529923	Plate
48	529966	Spring Washer
49	529924	Screw
50	617547	Washer
51	529925	Front Plate
52	617530	Pin
53	529926	Lock Lever Unit
54	529927	Pin
55	529928	Work Piece Contact A
56	529944	Pusher
57	617520	Guide
58	529967	Spring
60	617538	Screw
61	617511	Rear Plate
62	617536	Nut
63	617596	Cover
64	617512	Cover
65	529945	Movable Magazine Unit
66	617496	Rail
67	529946	Type Label Sequential
68	529947	Type Label Contact
69	529948	Fixed Magazine Unit Contact
70	529949	Fixed Magazine Unit Sequential
71	529950	Work Piece Contact B
72	529951	Support
73	617540	Screw
74	617541	Pin
75	617555	Lock
76	529937	Spring
77	529938	End Cap
78	529939	Ball Hook
79	529940	Screw
80	617534	Washer
81	617509	Air Plug
82	529979	Guide
83	529941	Manual

FN1850.2

ITEM	ITW-Eurocode	DESCRIPTION
	529909	FN1850.2 Sequential
1	617539	Screw
2	617556	Pushing
3	617504	Exhaust Cover
4	529913	Spring
5	617533	Screw
6	617535	Washer
7	617489	Cylinder Cap
8	617550	Gasket
9	617548	Seal
10	617519	Spring
11	617521	O-Ring
12	617510	Valve
13	617527	O-Ring
14	617507	Piston Stop
15	617552	Headrest Washer
16	617551	Cylinder Seal
17	617523	O-Ring
18	529914	Piston Unit
19	617505	Cylinder
20	617524	O-Ring
21	617525	O-Ring
22	617503	Collar
23	617522	O-Ring
24	617506	Bumper
25	617508	Joint Guide
26	617526	O-Ring
27	617545	Logo-1
28	617488	Body
29	529915	Trigger Valve Unit
30	529916	Spring
31	529917	Trigger Contact Kit
32	529918	Trigger Sequential
33	617537	Spring Pin
34	617553	Safety Bracket
35	529919	Spring
40	529920	Safety Lever Unit
41	617544	Logo-2
42	617549	Gasket
43	617529	Pin
44	529943	Driver Guide
45	617531	Screw
46	529922	Screw
47	529923	Plate
48	529966	Spring Washer
49	529924	Screw
50	617547	Washer
51	529925	Front Plate
52	617530	Pin
53	529926	Lock Lever Unit
54	529927	Pin
55	529928	Work Piece Contact A
56	529944	Pusher
57	617520	Guide
58	529967	Spring
60	617538	Screw
61	617511	Rear Plate
62	617536	Nut
63	617596	Cover
64	617512	Cover
65	529945	Movable Magazine Unit
66	617496	Rail
67	529946	Type Label Sequential
68	529947	Type Label Contact
69	529948	Fixed Magazine Unit Contact
70	529949	Fixed Magazine Unit Sequential
71	529950	Work Piece Contact B
72	529951	Support
73	617540	Screw
74	617541	Pin
75	617555	Lock
76	529937	Spring
77	529938	End Cap
78	529939	Ball Hook
79	529940	Screw
80	617534	Washer
81	617509	Air Plug
82	529979	Guide
83	529941	Manual