

| NO. | NAME                           | SPECIFICATION             | QTY | NO. | NAME                           | SPECIFICATION     | QTY |
|-----|--------------------------------|---------------------------|-----|-----|--------------------------------|-------------------|-----|
| 1   | Top cover                      | BMS60J1A-01-01-01         | 1   | 51  | Bearing                        | 6307              | 1   |
| 2   | Body                           | BMS70J1-01-02a            | 1   | 52  | Bearing                        | 6307              | 1   |
| 3   | Feet                           | BMS20J-01-15              | 4   | 53  | Flat key                       | A10x70            | 1   |
| 4   | Triangle belt                  | SPZ1320LW                 | 4   | 54  | Upper shaft weldment           | BMS70J-02-03-00   | 1   |
| 5   | Small triangle belt wheel      | BMS50J-02-01b             | 1   | 55  | Hook                           | BM15-02-09        | 1   |
| 6   | Flat key                       | A8x45                     | 1   | 56  | Hexagon socket cap screws      | M10X45            | 3   |
| 7   | Motor                          | BMS50J-04-01 double speed | 1   | 57  | Hexagon socket screw set screw | M8x10             | 4   |
| 8   | Hexagon headed bolt            | M10x30                    | 4   | 58  | Long pin                       | BMS20J-01-09      | 2   |
| 9   | Spring washer                  | 10                        | 4   | 59  | Protective net limit block     | BMS20J-01-13      | 1   |
| 10  | Large washer                   | 10                        | 4   | 60  | Switch wheel                   | BMS20J-01-10      | 1   |
| 11  | Triangle belt                  | A991                      | 2   | 61  | Protective cover               | BMS70J1-01-04     | 1   |
| 12  | Hexagon thin nut               | M16X1.5                   | 1   | 62  | Bowl                           | BM25-02-11        | 1   |
| 13  | Spring washer                  | 16                        | 1   | 63  | Lower shaft weldment           | BMS50J-02-13-00   | 1   |
| 14  | Flat washer                    | 16                        | 1   | 64  | Flat washer                    | 10                | 6   |
| 15  | Pulley 2                       | BMS50J-02-08              | 1   | 65  | Spring washer                  | 10                | 6   |
| 16  | Shaft sleeve                   | BMS50J-02-09              | 1   | 66  | Hex nut                        | M10               | 6   |
| 17  | Adjusting screw                | BMS50J-01-15              | 2   | 67  | Flat key                       | A10x32            | 1   |
| 18  | Bearing                        | UCFU206                   | 1   | 68  | Bearing                        | 6209              | 1   |
| 19  | Hex nut                        | M10                       | 4   | 69  | Bearing                        | 6209              | 1   |
| 20  | Spring washer                  | 10                        | 4   | 70  | Elastic washer for shaft       | 45                | 1   |
| 21  | Flat washer                    | 10                        | 4   | 71  | Elastic washers for holes      | 85                | 1   |
| 22  | Large washer                   | 10                        | 4   | 72  | Pulley 4                       | BMS50J-02-12      | 1   |
| 23  | Hexagon headed bolt            | M10x45                    | 4   | 73  | Flat washer                    | 24                | 1   |
| 24  | Flat key                       | A8x32                     | 1   | 74  | Spring washer                  | 24                | 1   |
| 25  | Upper and lower drive shaft    | BMS50J-02-10              | 1   | 75  | Hexagon thin nut               | M24x1.5           | 1   |
| 26  | Flat key                       | A8x32                     | 1   | 76  | Control panel pvc              | BMS60J1A-01-06-01 | 1   |
| 27  | Adjusting screw                | BMS50J-01-15              | 2   | 77  | Start button                   | LA138-10          | 3   |
| 28  | Bearing                        | UCFU206                   | 1   | 78  | Timer                          |                   | 1   |
| 29  | Hex nut                        | M10                       | 4   | 79  | Emergency stop button          | LA138-01ZS        | 1   |
| 30  | Spring washer                  | 10                        | 4   | 80  | Hex nut                        | M6                | 2   |
| 31  | Flat washer                    | 10                        | 4   | 81  | Spring washer                  | 6                 | 2   |
| 32  | Large washer                   | 10                        | 4   | 82  | Flat washer                    | 6                 | 2   |
| 33  | Hexagon headed bolt            | M10x45                    | 4   | 83  | Travel switch base             | BMS20J-01-12      | 1   |
| 34  | Pulley 3                       | BMS50J-02-11              | 1   | 84  | Cross groove head screw        | M6X16             | 2   |
| 35  | Flat washer                    | 16                        | 1   | 85  | Travel switch                  | SN7311            | 1   |
| 36  | Spring washer                  | 16                        | 1   | 86  | Power cord lockout             | M20x1.5           | 1   |
| 37  | Hexagon thin nut               | M16X1.5                   | 1   | 87  | Auxiliary contact              | F4-22             | 1   |
| 38  | Triangle belt                  | A1422                     | 2   | 88  | Auxiliary contact              | F4-02             | 2   |
| 39  | Back cover                     | BMS50J-01-08              | 1   | 89  | Ac contactor                   | CJX2-1210 380V    | 3   |
| 40  | Cross groove head screw        | M5X10                     | 6   | 90  | Terminal block                 |                   | 1   |
| 41  | Flat washer                    | 10                        | 4   | 91  | Electrical baseplate           | BMS20E-01-14-01   | 1   |
| 42  | Spring washer                  | 10                        | 4   | 92  |                                |                   |     |
| 43  | Hexagon socket head cap screws | M10X35                    | 4   | 93  |                                |                   |     |
| 44  | Fixed Stick                    | BMS70J-02-06              | 1   | 94  |                                |                   |     |
| 45  | Right-handed nut               | QRD105-01-05              | 1   | 95  |                                |                   |     |
| 46  | 3.5 Blade Washer               | QRD105-01-02              | 1   | 96  |                                |                   |     |
| 47  | Pulley 1                       | BMS50J-02-07              | 1   | 97  |                                |                   |     |
| 48  | Big triangle belt wheel        | BMS50J-02-02b             | 1   | 98  |                                |                   |     |
| 49  | Elastic washers for holes      | 80                        | 1   | 99  |                                |                   |     |
| 50  | Elastic washer for shaft       | 35                        | 1   | 100 |                                |                   |     |