

DH-200 PART LIST / RESERVDELSLISTA

SKU / Art.nr: GTS-DH200

NO	NAME	SPECIFICATION	QTY	NO	NAME	SPECIFICATION	QTY
1	Top cover	BM75-01-10	1	41	Auxiliary motor pulley	BM100-02-24	1
2	Body	BM75-01-01-00	1	42	Auxiliary motor	BM100-02-28	1
3	Back cover	BM75 -01-02	1	43	Auxiliary motor seat	BM100-02-25	1
4	Cutting v-belt	XPA1950	6	44	Circlip for shaft	20	1
5	Main motor pulley	BM100-02-03	1	45	Circlip for shaft	20	1
6	Main motor	YD160M-8/4 (4/9 kW)	1	46	Motor seat pin shaft	BM100-02-26	1
7	Bearing pedestal on mixing shaft	BM100-02-08	1	47	Motor seat adjusting screw	BM100-02-27	1
8	Bearing	6212	1	48	Turn pin with keyway	BML120-01-12-02	1
9	Driven pulley	BM100-02-04	1	49	Switch pressure wheel	BML40-01-13	1
10	Small round nut	M64×2	2	50	Movable cover limit block	BM100-01-07	1
11	Lock washer	64	1	51	No keyway turnpin	BML120-01-12-01	1
12	Bearing	6313	1	52	Limit block iron of the protective net	BM100-01-09	2
13	Mixing shaft	BM100-02-05	1	53	Limit switch seat	BM100-01-08	1
14	Bearing pedestal under mixing shaft	BM100-02-07	1	54	Limit switch	SN7311	1
15	Dust seal	BM100-02-06	1	55	Control load switch	SZD11-32	1
16	Hook	BM75 -02-09	1	56	A.C contactor	LC1E3201M5N/220V	1
17	Fixed rod	BM75 -02-10	1	57	A.C contactor	LC1E3201M5N/220V	2
18	Safety net	BM75-01-03a	1	58	A.C contactor	LC1E0601M5N/220V	2
19	Fixed cover	BM100-01-04	1	59	Thermorelay	LRE32N 16-24A	1
20	Bowl	BM75 -02-11	1	60	Thermorelay	LRE21N 9-13A	1
21	Ring on lower shaft	BM100-02-16	1	61	Thermorelay	LRE08N 2.5-4A	1
22	Shaft flange	BM100-02-12	1	62	Transformer	JBK3-63VA	1
23	Lower shaft	BM100-02-13	1	63	Phase sequence relay	XJ3-G 380V	1
24	Oil seal	B85×120×12	1	64	Electrical plate	BM75-01-14	1
25	Bearing	6213	2	65	Time limit relay	AH2-Y 30M 220V	2
26	Lower bearing seat	BM100-02-14	1	66	Transfer switch	ZB2 BD2C	2
27	Bearing	6213	1	67	Start switch	ZB2-BP3C BZ101C	4
28	Circlip for hole	120	1	68	Signal light	XB2-BVM4LC	1
29	Circlip for shaft	65	1	69	Stop button switch	ZB2BS54C BZ102C	1
30	Lower shaft chain wheel	BM100-02-15	1	70	Caster shaft	BM75-01-19	2
31	Lower shaft lower circlip	BM100-02-17	1	71	Caster	BM100-01-18	4
32	Chain	08B-2 132 section	2	72	Support seat press plate	BM100-01-21	4
33	Circlip on bridge shaft	BM100-02-19	1	73	Star shape handle	BML40-02-25	4
34	Bearing	6206	1	74	Feet adjustment seat	BML40-02-22	4
35	Lower bridge shaft	BM100-02-18	1	75	Feet	BML40-02-23	4
36	Bearing	6206	1				
37	Bridge bearing pedestal	BM100-02-21	1				
38	Bridge axle pulley	BM100-02-23	1				
39	Circlip under bridge shaft	BM100-02-20	1				
40	Triangle belt	7M-1320	3				