

## AZ-P1 Super Pro 9x19 Parts List

<b>C.</b>	<b>Name</b>		<b>C.</b>	<b>Name</b>	
1	Giant frame	22-P1-100-01-03-00	48	Firing pin longer	22-P1-200-06-01-01
2	Backstrap Sport/Super Magwel 2	22-P1-100-02-03-00	49	Firing pin spring II soft	22-P1-200-07-01-00
3	Magazine catch - Sport	22-P1-100-03-00-00	50	Thumb rest securing screw Torx M4x6	22-P1-100-73-00-00
4	9mm magazine catch pin	22-P1-100-04-00-00	51	Thumb rest securing screw Torx M4x5	22-P1-100-50-00-00
5	Magazine catch spring	22-P1-100-05-00-00	52	Buffer II	22-P1-200-10-00-00
6	Trigger block	22-P1-100-06-00-00	53	Recoil spring	22-P1-200-11-00-00
7	Sliding trigger base SA	22-P1-108-01-00-00	54	Recoil spring guide rod	22-P1-200-12-00-00
8	SA/DA slide trigger tab	22-P1-108-02-00-00	55	Front sight	22-P1-200-13-00-00
9	Standard trigger spring	22-P1-100-09-00-00	56	Optics extractor pin 2.5x10	22-P1-200-05-01-00
10	Slice catch	22-P1-100-10-00-00	57	Front sight pin 1.5x10	22-P1-200-15-00-00
11	Slide catch spring	22-P1-100-12-00-00	58	9 mm S.F.Meccanica magazine	22-P1-900-00-05-00
12	Trigger pin	22-P1-100-14-00-00	59	Plastic tray feeder SFMeccanica	
13	SA trigger bar	22-P1-100-15-01-02	60	SFMeccanica magazine spring	
14	Trigger bar spring	22-P1-100-16-00-00	61	Floorplate +2 M3x6	22-P1-900-07-00-00
15	Ejector	22-P1-100-17-00-00	62	Floorplate +2	22-P1-900-06-00-00
16	Hammer catch	22-P1-100-18-03-00	63	Zendl sight base	22-P1-200-17-00-00
17	Hammer catch screw M3x5	22-P1-100-19-00-00	64	Trigger screw SA M3x6 safety tooth	22-P1-100-07-01-00
18	Ejector screw Allen M2.5x6	22-P1-100-22-00-00	65	Trigger screw SA spring M3x4	22-P1-100-07-02-00
19	Hammer catch pin	22-P1-100-21-00-00	66	Trigger screw SA M3x5 tab	22-P1-100-07-03-00
20	Lock lever	22-P1-100-20-00-00	67	Torx screw for sight base M3x6	22-P1-200-20-00-00
21	SA hammer	22-P1-100-23-05-00	68	Zendl rear sight flap	22-P1-200-14-01-00
22	Hammer pin	22-P1-100-24-00-00	69	Magwell 1 Super Pro/ Vigil-long	22-P1-100-53-04-00
23	Main spring guide rod – series II	22-P1-100-25-01-00	70	Magwell screw Torx M3x16	22-P1-100-51-00-00
24	Main spring guide rod pin 2.5h6x8	22-P1-100-26-00-00	71	Thumb rest 1 Super Pro	22-P1-100-80-01-00
25	Main spring II	22-P1-100-27-01-00			
26	Hammer catch spring	22-P1-100-28-00-00			
27	Hammer catch spring pin	22-P1-100-29-00-00			

<b>28</b>	Front block pin 2.5x24	<b>22-P1-100-31-00-00</b>			
<b>29</b>	Rear block pin 2.5x22	<b>22-P1-100-30-00-00</b>			
<b>30</b>	Disassembling pin	<b>22-P1-100-32-00-00</b>			
<b>31</b>	Disassembling pin spring	<b>22-P1-100-33-00-00</b>			
<b>32</b>	Left safety	<b>22-P1-100-34-00-00</b>			
<b>33</b>	Right safety	<b>22-P1-100-35-00-00</b>			
<b>34</b>	Fuse latch	<b>22-P1-100-36-00-00</b>			
<b>35</b>	Fuse latch spring	<b>22-P1-100-37-00-00</b>			
<b>36</b>	Spiral safety pin 1.5x16	<b>22-P1-100-38-00-00</b>			
<b>37</b>	Left grip Sport	<b>22-P1-100-39-00-00</b>			
<b>38</b>	Right grip Sport	<b>22-P1-100-40-00-00</b>			
<b>39</b>	Grip screw Torx M4x5	<b>22-P1-100-50-00-00</b>			
<b>40</b>	Trigger bar spring pin 1.5x10	<b>22-P1-100-47-00-00</b>			
<b>41</b>	Trigger screw SA flat free movement M3x6	<b>22-P1-100-07-01-00</b>			
<b>42</b>	Backstrap pin	<b>22-P1-100-49-00-00</b>			
<b>43</b>	9mm Super Pro/ Special slide	<b>22-P1-200-01-07-0A</b>			
<b>44</b>	Barrel 9mm	<b>22-P1-200-02-00-00</b>			
<b>45</b>	9x19 extractor	<b>22-P1-200-03-05-00</b>			
<b>46</b>	Extractor spring soft	<b>22-P1-200-04-00-00</b>			
<b>47</b>	Spiral firing pin pin, locking 2.5x18	<b>22-P1-200-16-02-00</b>			