

BATTERY POWERED PENDANT LIGHT TERLIZZI



User Manual

DE	Benutzerhandbuch	LT	Vartotojo vadovas
BG	Ръководство за потребителя	LV	Lietotāja rokasgrāmata
CZ	Uživatelská příručka	NL	Gebruikershandleiding
DK	Brugervejledning	NO	Brukerhåndbok
EE	Kasutusjuhend	PL	Podręcznik użytkownika
ES	Manual del usuario	PT	Manual do utilizador
FI	Käyttäjän käsikirja	RO	Manual de utilizare
FR	Manuel d'utilisation	SE	Användarmanual
GR	Εγχειρίδιο χρήστη	SI	Uporabniški priročnik
HR	korisnički priručnik	SK	Používateľská príručka
HU	Felhasználói kézikönyv	TR	Kullanıcı Kılavuzu
IT	Manuale d'uso		

EN User Manual	6	(EU)
DE Benutzerhandbuch	9	(D)
BG ръководство за потребителя	12	(B)
CZ Uživatelská příručka	15	(CZ)
DK Brugervejledning	18	(DK)
EE Kasutusjuhend	21	(EST)
ES Manual del usuario	24	(ES)
FI Käyttäjän käsikirja	27	(FIN)
FR Manuel d'utilisation	30	(F) (B)
GR Εγχειρίδιο χρήστη	33	(GR)
HR Felhasználói kézikönyv	36	(HR)
HU Felhasználói kézikönyv	39	(HU)
IT Manuale d'uso	42	(I)
LT Vartotojo vadovas	45	(LT)
LV Lietotāja rokasgrāmata	48	(LV)
NL Gebruikershandleiding	51	(NL) (B)
NO Brukerhåndbok	54	(N)
PL Podręcznik użytkownika	57	(PL)
PT Manual do utilizador	60	(PRT)
RO Manual de utilizare	63	(RO)
SE Användarmanual	66	(S)
SI Uporabniški priročnik	69	(SLD)
SK Používateľská príručka	72	(SK)
TR Kullanıcı Kılavuzu	75	(TR)




Electro Cirkel Retail B.V.
Lyonstraat 29
3047 AJ Rotterdam
The Netherlands

Calex Smart Home UK Ltd.
20 Gresham Street London
EC2V 7JE United Kingdom

WWW.CALEX.EU

1




2



3

3



4





Safety



Conformity with all relevant requirements of the EU directive.

If applicable:

Use this device only for its intended purpose;

Do not use this device if it is damaged or defective.

Choose a location for the product where there is no risk of the cable being stepped on or tripped over. Do not place any objects on the cable.

If this product is damaged, especially if the cable or fitting is damaged, this product must be switched off immediately. In this case, replacement is required;

Before replacing it, turn off the power and let it cool down to avoid electric shock or burns.

The adapter (if applicable) must be installed near the unit, must not be connected to another adapter, and must be easily accessible.

Products should only be used with the original adapter.

This product should only be opened by a qualified technician if maintenance is required.

Never perform repairs yourself.

If this product is passed on to third parties, manuals must be included.



Choking hazard. Because packaging materials can be swallowed or misused, there is a risk of choking or injury. Keep packaging materials away from children.

Warranty

Any changes and/or modifications to the product will void the warranty. We cannot accept liability for damage caused by improper use of the product. Go to help.calex.eu for more information.

Disclaimer

Designs and specifications are subject to change without notice. All logos, brands and product references used are trademarks or registered trademarks of their respective holders and are hereby acknowledged as such.

Recycling



This product is labelled with this crossed out wheel bin symbol in accordance with European Directive 2012/19/EU to indicate that it must not be disposed of with your other household waste. Due to the presence of hazardous substances, mixtures or components, electrical and electronic devices that are not subject to selective sorting are potentially dangerous to the environment and human health. Please check your local city office or waste disposal service for the return and recycling of this product.

Explanation Safety Classes

-  Safety class I: Metal parts of equipment that fall into this class are connected to an earth protection conductor. If the product has a plug, it must be connected to an earthed socket; products that require installation are equipped with a ground terminal and must therefore be earthed; connect the ground wire (yellow green vein) to the -marked terminal.
-  Safety Class II: This product or any part of it is double insulated and does not need to be connected to a grounded outlet.
-  Safety Class III: Equipment in this group operates at an extra low voltage of less than 50 volts alternating current. For example, 24 volts.

The safety class is indicated on the product.

Explanation IP (Ingress Protection) Values

- IP20 Protected against solid objects greater than 12mm. No protection against liquids.
- IP44 Protected against solid objects greater than 1mm. Protection against vertical splashing water at an angle up to 60°.
- IP54 Prevents ingress of dust sufficient to cause harm. Protection against vertical splashing water at an angle up to 60°.
- IP65 Dust tight. No ingress of dust. Protected against powerful jets of water from all directions. Limited liquid entry.

Installation and operation

1. Insert 4 AA batteries (not included) into the battery compartment.
2. Install the bulb into the pendant light by turning it counterclockwise to fasten the bulb into the socket. Use the supplied LED G125 3V E27 bulb only. Regular bulbs are not suitable for this pendant, and the supplied bulb is also not suitable for regular lampholders.
3. Remote control
 - A. Remove the insulating plastic sheet.
 - B. Press the "ON" button to turn on the bulb.
 - C. Press the "OFF" button to turn off the bulb.
 - D. Timer: The bulb will turn on for 6 hours and off for 18 hours, repeating until you press the "OFF" button.
4. Switch control
 - Press the button once to turn on the bulb.
 - Press the button twice to enter the timing mode.
 - Press the button three times to turn off the bulb.
 - Timer: the bulb will turn on for 6 hours and off for 18 hours and repeats this schedule until the button is pressed again (off mode).
5. Hang the lamp in the desired location and test the lamp and remote control for proper operation.